


Leslie[®] Speakers

147 & 147 RV



- ◆ Single channel, two rotors
- ◆ Large cabinet for lower pedal range
- ◆ 40 watts continuous undistorted power
- ◆ 15-inch bass speaker, frequency-selective treble speaker
- ◆ Cross-over network

The Leslie Model 147 closely resembles the Model 145, except that the larger cabinet size produces a more responsive bass. Thus, the 147 is recommended for larger organs whose pedal range extends down to the lower frequencies. The sound is "separated", with the highs produced by the spinning horn rotor and the lows coming from the bass rotor. With the rotors turning at fast speed, an exciting tremolo is created...while the slower speed produces an ethereal chorale. The physical separation of the speaker cabinet from the organ console speaker creates a unique stereophonic effect—a duet of music in motion. The Model 147 RV contains all the components of the 147, plus a reverb generator and independent reverb channel. This reverb system utilizes a separate 15 watt amplifier and stationary speaker. Both the 147 and 147 RV blend these electronic and acoustic effects into a truly memorable listening experience...stereophonic in effect...filling the room with sound in motion.

Specifications

Dimensions: Height 41", Width 29", Depth 20½"

Amplification: Measured continuous undistorted output 40 watts (RMS)

Controls: Switch for Fast (Tremolo) and Slow (Chorale). Separate speaker selector for switching between built-in console speaker, Leslie speaker or both together. 3-position reverb control (off-medium-full).

Electrical: 117 V, 60 Hz. AC.

Weight: Model 147, 136 pounds. Model 147 RV 156 pounds.

Guarantee: One year from date of purchase.

Electro Music/CBS Musical Instruments,
A Division of Columbia
Broadcasting System, Inc.
Bin 30, Arroyo Annex
Pasadena, California 91109

Leslie is a Registered Trademark of CBS, Inc.

Printed in U.S.A.

Leslie

Block diagram of function.

